






<p>i 9 208 774 (NL 500) 9 208 779 (NL 550)</p>	<p>9 208 776 (NL 500) 9 208 783 (NL 550)</p>	<p>9 208 777 (NL 500) 9 208 784 (NL 550)</p>	<p>9 208 778 (NL 500) 9 208 785 (NL 550)</p>
---	--	--	--



i

Nur handelsübliche, wasserlösliche Reinigungsmittel benutzen, keine aggressiven, scheuernden Mittel verwenden.

Use only standard water-soluble cleaning agents. Do not use aggressive or scouring agents!

Utiliser uniquement des nettoyeurs courants solubles à l'eau, ne pas utiliser de nettoyeurs agressifs récurants.

Gebruik uitsluitend in de handel gebruikelijke, in water oplosbare schoonmaakmiddelen, gebruik geen agressieve, schurende middelen.